

Entour Haze Pro		1 Channel Mode
Channel	Value	Function
1	0 - 4	OUTPUT VOLUME & FAN SPEED NO OUTPUT VOLUME 5% FAN SPEED
	5 - 255	100% OUTPUT VOLUME 100% FAN SPEED

Entour Haze Pro		2 Channel Mode
Channel	Value	Function
1	0 - 4	OUTPUT VOLUME NO OUTPUT VOLUME
	5 - 255	100% OUTPUT VOLUME
2	0 - 15	FAN SPEED 5% FAN SPEED
	16 - 255	6%-100% FAN SPEED

Note: In 2 channel mode, when using channel 1 only, the default fan speed is 30%.

Entour Haze Pro		4 Channel Mode
Channel	Value	Function
1	0 - 4	OUTPUT VOLUME NO OUTPUT VOLUME
	5 - 255	100% OUTPUT VOLUME
2	0 - 15	FAN SPEED 5% FAN SPEED
	16 - 255	6%-100% FAN SPEED
3	0 - 7	DURATION 3 SECONDS
	8 - 255	3-250 SECONDS
4	0 - 9	INTERVAL 0 SECONDS
	10 - 255	5-250 SECONDS

Note: In 4 channel mode, when using channel 1 only, the default fan speed is 30%.

