

Mode/Channel				Value	Function
1CH	2CH	3CH	4CH		
1	1	1	1	0-255	<a href="#">Dimmer</a> Master Dim
			2	0-255	<a href="#">Dimmer Fine</a> 16bit
	2	2	3		<a href="#">Strobe</a>
				0-31	OFF
				32-63	ON
				64-95	Variable Strobe slow to fast
				96-127	ON
				128-159	Pulse Effect slow to fast
				160-191	ON
				192-223	Random Strobe slow to fast
				224-255	ON
		3	4		<a href="#">Dim Mode</a>
				0-20	Standard
				21-40	Stage
				41-60	TV
				61-80	Architectural
				81-100	Theatre
				101-255	Default to Unit Setting