

## Firmware update for ADJ 4 Stream DMX Bridge

1. Unzip the firmware update folder containing the files.
2. Connect your 4 Stream Bridge to your Windows PC with a USB cable.
3. Put the bridge into bootloader mode by holding down the “enter” button on power-up. The display will show “Bootloader Mode”.
4. Run the bootloader application "ADJ\_4Stream\_Bridge\_USB\_Bootloader" directly from the update folder.
5. Wait until the bootloader application shows "connected" in lower right.
6. Click the “Load File” button then navigate to and select the firmware file “ADJ 4 Stream V4.cyacd” that's included in the folder.
7. Click the "program" button and wait until finished programming. The log display should show “Bootload successful !!”.
8. The bridge will restart automatically after the firmware update has loaded and the bootload application will disconnect. The screen on the bridge should show V-4 in the lower right when displaying the title screen.