

ADJ ENCORE PROFILE PRO COLOR DMX CHANNEL FUNCTIONS & VALUES

Supports Software Versions: ≥ 1.04						
CHANNEL					DMX VALUES	FUNCTION
2CH	4CH	13CH	14CH	16CH		
		1	1	1	000 - 255	Red , 0% - 100%
		2	2	2	000 - 255	Green , 0% - 100%
		3	3	3	000 - 255	Blue , 0% - 100%
		4	4	4	000 - 255	White , 0% - 100%
		5	5	5	000 - 255	Amber , 0% - 100%
		6	6	6	000 - 255	Lime , 0% - 100%
	1	7	7	7	000 - 255	Color Temperature (see Color Temperature Table section of this manual)
						Color Temperature Presets
					000 - 031	No Function
					032 - 076	2700K
	2	8	8	8	077 - 121	3200K
					122 - 166	4000K
					167 - 211	5600K
					212 - 255	6500K
						Color Temperature, Red to Green
		9	9	9	000	No Function
					001 - 255	Shift CT Red to Green
		10	10	10	000 - 255	Color Macros , (see Color Macros Chart section of this manual)
						Shutter
					000 - 031	Shutter Closed (LEDs Off)
					032 - 063	Shutter Open (LEDs On)
					064 - 095	Strobe effect, slow to fast
		11	11	11	096 - 127	Shutter Open (LEDs On)
					128 - 159	Pulse effect in sequences
					160 - 191	Shutter Open (LEDs On)
					192 - 223	Random Strobe Effect, slow to fast
					224 - 255	Shutter Open (LEDs On)
1	3	12	12	12	000 - 255	Dimmer Intensity , 0% - 100%
2	4	13	13	13	000 - 255	Dimmer Fine
						Dim Modes
					000 - 020	Default to Unit Setting
			14	14	021 - 040	Standard
					041 - 060	Stage
					061 - 080	TV

CONTINUED ON NEXT PAGE

ADJ ENCORE PROFILE PRO COLOR DMX CHANNEL FUNCTIONS & VALUES

Supports Software Versions: ≥ 1.04

CHANNEL					DMX VALUES	FUNCTION
2CH	4CH	13CH	14CH	16CH		
						<i>Dim Modes</i> (continued from previous page)
					081 - 100	Architectural
					101 - 120	Theatre
					121 - 140	Stage 2
						<i>Dimming Speed</i>
					141	0.1 s
					142	0.2 s
					143	0.3 s
					144	0.4 s
					145	0.5 s
					146	0.6 s
					147	0.7 s
					148	0.8 s
					149	0.9 s
					150	1 s
					151	1.5 s
					152	2 s
					153	3 s
					154	4 s
					155	5 s
					156	6 s
					157	7 s
					158	8 s
					159	9 s
					160	10 s
					161 - 255	Default to Unit Setting
						<i>Dim Curves</i>
					000 - 020	Square
					021 - 040	Linear
					041 - 060	Inv. Squa
					061 - 080	S. Curve
					081 - 255	No Function

CONTINUED ON NEXT PAGE

ADJ ENCORE PROFILE PRO COLOR DMX CHANNEL FUNCTIONS & VALUES

Supports Software Versions: ≥ 1.04

CHANNEL					DMX VALUES	FUNCTION
2CH	4CH	13CH	14CH	16CH		
						<i>LED Refresh Rates</i>
					000 - 028	1200 Hz (Default)
					029	1080 Hz
					030	1090 Hz
					031	1100 Hz
					032	1110 Hz
					033	1120 Hz
					034	1130 Hz
					035	1140 Hz
					036	1150 Hz
					037	1160 Hz
					038	1170 Hz
					039	1180 Hz
					040	1190 Hz
					041	1210 Hz
					042	1220 Hz
					043	1230 Hz
				16	044	1240 Hz
					045	1250 Hz
					046	1260 Hz
					047	1270 Hz
					048	1280 Hz
					049	1290 Hz
					050	1300 Hz
					051	1310 Hz
					052	1320 Hz
					053	1330 Hz
					054	1340 Hz
					055	1350 Hz
					056	1360 Hz
					057	1370 Hz
					058	1380 Hz
					059	1390 Hz
					060	1400 Hz
					061	1410 Hz

CONTINUED ON NEXT PAGE

ADJ ENCORE PROFILE PRO COLOR DMX CHANNEL FUNCTIONS & VALUES

Supports Software Versions: ≥ 1.04						
CHANNEL					DMX VALUES	FUNCTION
2CH	4CH	13CH	14CH	16CH		
				16		LED Refresh Rates (continued from previous page)
					062	1420 Hz
					063	1430 Hz
					064	1440 Hz
					065	1450 Hz
					066	1460 Hz
					067	1470 Hz
					068	1480 Hz
					069	1490 Hz
					070	1500 Hz
					071	2500 Hz
					072	4000 Hz
					073	5000 Hz
					074	6000 Hz
					075	10K Hz
					076	15K Hz
					077	20K Hz
					078	25K Hz
					079	Disable LED Refresh Rate
					080 - 255	No Function