



AVANTE IMPERIO PRO IMP 118 - FREQUENCY CHARTS

SPL VS. FREQ CHART, 100 Hz



SPL VS. FREQ CHART, 60 Hz / 100 Hz / 150Hz



KEY: Gray = 60 Hz, Red = 100 Hz, Green = 150 Hz