

# ADJ VIZI BEAM CMY - DMX TRAITS

CHANNEL		DMX VALUE	FUNCTION
20CH	24CH		
1	1	000-255	<b>Pan</b>
	2	000-255	<b>Pan Fine</b>
2	3	000-255	<b>Tilt</b>
	4	000-255	<b>Tilt Fine</b>
3	5	000-255	<b>Cyan 0 -100%</b>
4	6	000-255	<b>Magenta 0 - 100%</b>
5	7	000-255	<b>Yellow 0 - 100%</b>
6	8		<b>Color</b>
		000-003	White
		004-007	Color1
		008-011	Color2
		012-015	Color3
		016-019	Color4
		020-023	Color5
		024-027	Color6
		028-031	Color7
		032-035	Color8
		036-039	Color9
		040-043	Color10
		044-047	Color11
		048-051	Color12
		052-055	Color13
		056-059	Color14
		060-061	White
		062-063	White to Color1
		064-065	Color1
		066-067	Color1 to Color2
		068-069	Color2
		070-071	Color2 to Color3
		072-073	Color3
		074-075	Color3 to Color4
		076-077	Color4
		078-079	Color4 to Color5
		080-081	Color5
		082-083	Color5 to Color6
		084-085	Color6
		086-087	Color6 to Color7
		088-089	Color7
		090-091	Color7 to Color8
		092-093	Color8
		094-095	Color8 to Color9
		096-097	Color9
098-099	Color9 to Color10		
100-101	Color10		
102-103	Color10 to Color11		
104-106	Color11		
107-109	Color11 to Color12		
110-112	Color12		
113-115	Color12 to Color13		
116-118	Color13		
119-121	Color 13 to Color14		
122-124	Color14		
125-127	Color14 to White		
128-189	Clockwise Rotation Fast to Slow		
190-193	Stop		
	194-255	Counter-Clockwise Rotation Slow to Fast	

# DMX TRAITS

CHANNEL		DMX VALUE	FUNCTION
20CH	24CH		
7	9		<b>Color Macros - CMY and Color Wheel</b>
		000-031	OFF
		032-039	Macro1
		040-047	Macro2
		048-055	Macro3
		056-063	Macro4
		064-071	Macro5
		072-079	Macro6
		080-087	Macro7
		088-095	Macro8
		096-103	Macro9
		104-111	Macro10
		112-119	Macro11
		120-127	Macro12
		128-135	Macro13
		136-143	Macro14
		144-151	Macro15
		152-159	Macro16
		160-167	Macro17
		168-175	Macro18
		176-183	Macro19
		184-191	Macro20
		192-199	Macro21
		200-207	Macro22
		208-215	Macro23
		216-223	Macro24
		224-231	Macro25
232-239	Macro26		
240-247	Macro27		
248-255	Random CMY		
8	10		<b>Multicolor Effect</b>
		000-007	Close
		008-255	Open

# DMX TRAITS

CHANNEL		DMX VALUE	FUNCTION
20CH	24CH		
9	11		<b>Static Gobo</b>
		000-007	Open
		008-010	Gobo1
		011-013	Gobo2
		014-016	Gobo3
		017-019	Gobo4
		020-022	Gobo5
		023-025	Gobo6
		026-028	Gobo7
		029-031	Gobo8
		032-034	Gobo9
		035-037	Gobo10
		038-040	Gobo11
		041-043	Gobo12
		044-046	Gobo13
		047-049	Gobo14
		050-052	Gobo15
		053-055	Gobo16
		056-059	Open Shaking Slow to Fast
		060-063	Gobo1 Shaking Slow to Fast
		064-067	Gobo2 Shaking Slow to Fast
		068-071	Gobo3 Shaking Slow to Fast
		072-075	Gobo4 Shaking Slow to Fast
		076-079	Gobo5 Shaking Slow to Fast
		080-083	Gobo6 Shaking Slow to Fast
		084-087	Gobo7 Shaking Slow to Fast
		088-091	Gobo8 Shaking Slow to Fast
		092-095	Gobo9 Shaking Slow to Fast
		096-099	Gobo10 Shaking Slow to Fast
		100-103	Gobo11 Shaking Slow to Fast
104-107	Gobo12 Shaking Slow to Fast		
108-111	Gobo13 Shaking Slow to Fast		
112-115	Gobo14 Shaking Slow to Fast		
116-119	Gobo15 Shaking Slow to Fast		
120-127	Gobo16 Shaking Slow to Fast		
128-189	Clockwise Rotation Fast to Slow		
190-193	Stop		
194-255	Counter-Clockwise Rotation Slow to Fast		
10	12		<b>Prism1</b>
		000-007	Close
		008-255	Open
11	13		<b>Prism1 Rotation</b>
		000-127	0% ~ 100%
		128-189	Clockwise Rotation Fast to Slow
		190-193	Stop
		194-255	Counter-Clockwise Rotation Slow to Fast

# DMX TRAITS

CHANNEL		DMX VALUE	FUNCTION
20CH	24CH		
12	14		<b>Prism2</b>
		000-007	Close
		008-255	Open
13	15		<b>Prism2 Rotation</b>
		000-127	0% ~ 100%
		128-189	Clockwise Rotation Fast to Slow
		190-193	Stop
		194-255	Counter-Clockwise Rotation Slow to Fast
14	16		<b>Shutter</b>
		000-031	Close
		032-063	Open
		064-095	Strobe from Slow to Fast
		096-127	Open
		128-159	Pulse Effect in sequence
		160-191	Open
		192-223	Random Strobe Slow to Fast
	224-255	Open	
15	17	000-255	<b>Dimmer 0 - 100%</b>
	18	000-255	<b>Dimmer Fine 0 - 100%</b>
16	19	000-255	<b>Focus 0 - 100%</b>
	20	000-255	<b>Focus Fine 0 - 100%</b>
17	21	000-255	<b>Frost 0 - 100%</b>
18	22	000-255	<b>CMY Speed Fast to Slow</b>
19	23	000-255	<b>Pan/Tilt Speed Fast to Slow</b>
20	24		<b>Special</b>
		000-069	Null
		070-079	Enable blackout while Pan/Tilt moving
		080-089	Disable blackout while Pan/Tilt moving
		090-099	Enable blackout while color changing
		100-109	Disable blackout while color changing
		110-119	Enable blackout while gobo changing
		120-129	Disable blackout while gobo changing
		130-139	Lamp On
		140-149	Reset XY
		150-159	Reset Effect
		160-169	Reset Color (Color Wheel and CMY)
		170-199	No Function
		200-209	Reset All
		210-229	No Function
		230-239	Lamp Off
	240-255	No Function	