



Folder /song List toggle

FX 1  
Control

FX 3  
Control

FX 2  
Control

The middle knob is the value for  
chosen FX and the push action  
Becomes FX on/off. Turn on the  
Mixer FX with the "Pause" button.