

DMX VALUES & TRAITS

Channel	Value	Function
1	0 - 7 8 - 15 16 - 131 132 - 139 140 - 181 182 - 189 190 - 231 232 - 239 240 - 247 248 - 255	STROBING/SHUTTER CLOSED OPEN STROBE SLOW - FAST OPEN FAST CLOSE - SLOW OPEN OPEN SLOW CLOSE - FAST OPEN OPEN RANDOM STROBE OPEN
2	0 - 255	MASTER DIMMER 0% - 100%
3	0 - 20 21 - 40 41 - 60 61 - 80 81 - 100 101 - 255	DIMMER MODE STANDARD STAGE TV ARCHITECTURAL THEATRE DEFAULT DIMMER SETTING

Fog Fury Jett		5 Channel Mode
Channel	Value	Function
1	0 - 15 16 - 31 32 - 255	FOG & RANDOM COLOR CHANGE OFF COLOR MACRO PREVIEW MAX FOG & COLOR CHANGE
2	0 - 255	RED 0% - 100%
3	0 - 255	GREEN 0% - 100%
4	0 - 255	BLUE 0% - 100%
5	0 - 255	AMBER 0% - 100%
Fog Fury Jett		7 Channel Mode
Channel	Value	Function
1	0 - 15 16 - 31 32 - 255	FOG & RANDOM COLOR CHANGE OFF COLOR MACRO PREVIEW MAX FOG & COLOR CHANGE
2	0 - 255	RED 0% - 100%
3	0 - 255	GREEN 0% - 100%
4	0 - 255	BLUE 0% - 100%
5	0 - 255	AMBER 0% - 100%
6	0 - 31 32 - 95 96 - 159 160 - 255	STROBING OFF STROBING SLOW - FAST PULSE EFFECT RANDOM STROBE SLOW - FAST
7	0 - 255	MASTER DIMMER 0% - 100%

Color Macros/RGBA will not work unless fog is active.